

Application of Configur8 Concrete tiles needs a great deal of skill and attention to detail. Approved competent contractors should be employed with experience of similar projects fixing natural stone or concrete products. When installing Configur8 tiles on a facade, be sure that you consult the manufacturer beforehand.

GENERAL INSTRUCTIONS

- a. Check load bearing capacity of the substrate and always compare with the weight per square metre (square feet) of the tile. For more information please check the Technical Sheets provided on our website.

- b. Tiling operations should be carried out in ambient temperatures 10–30 °C / 50–86 °F

- c. Before starting work, the background has to dry with exposure to air for not less than the following:
 - concrete walls – 6 weeks
 - brickwork or blocwork walls – 6 weeks
 - rendering sand and cement – 2 weeks